


Changing Crops (Ex.-Corn to Beans – Hyd. Drive)


1. Main Work Screen;
Push Next Page

2. Push Summary Button.
(If Already In User Level 2,
Skip To Step 6)


3. Push Password Button




4. Enter 2 + 5 Digit Serial # of WSMT & Push OK;





5. Push the “ESC” Soft Key to Return to Summary Screen




6. Push Channel # 1 Type - Planter Control




7. Push “Material Name”;
Change to Beans, Then
Push the “ESC” Soft Key.




8. Verify Changes in Material
Name On Summary Screen.




9. Push Channel 2 Button
At Top Of Screen




10. Push Channel #2; “Material Name” Split-Air




11. Change Target Rate To 2.00.
Push The “ESC” Soft Key to
Return to Summary Screen



12. Verify Changes In Channel 2
 “Material Name”.



13. Return To Main Work Screen



14. Ready To Plant Beans